



3 AAA, LR03 elemmel működik, nem tartozék.

Behelyezés és elemcsere

A modelltől függően csavarhúzóval távolítsa el a fedelet. Tegye be az AAA, LR03 elemeket, ügyelve a jelzett polaritásra. Helyezze vissza a fedelet úgy, hogy az ugyanoda kerüljön.

Mágnes a hátoldalon

Figyelmeztetések

A nem újratölthető akkumulátorokat nem szabad újratölteni. Az újratölthető elemeket el kell távolítani a termékből, mielőtt feltöltve. Különböző típusú akkukat vagy új és használt akkukat nem szabad összekeverni. Az akkumulátorokat a megfelelő polaritással kell behelyezni. A lemerült elemeket el kell távolítani (a termékből). A beszállítói csatlakozókapcsokat nem szabad rövidre zárni. Az elemeket tartsa távol (rom gyermekektől).

LED DISPLAY



UP TO



VISSZASZÁMLÁLÓ

- Forgassa el a gombot a kívánt idő beállításához.
- Miután beállította a visszaszámlálási időt, nyomja meg egyszer a gombot a számlálás megkezdéséhez 
- Amikor a visszaszámlálási idő 00 perc 00 másodpercig tart, a digitális időzítő zúg, a képernyő villogni fog, a riasztási hang 60 másodpercig szól.
- A zümmögést a gomb megnyomásával lehet leállítani 
- Nyomja meg a hangerő gombot a megfelelő hangerő kiválasztásához.

STOPWATCH

- Nyomja meg és tartsa lenyomva a gombot a nulla törléséhez @
- Amikor a kijelzőn 00 perc 00 másodperc jelenik meg, nyomja meg a gombot.

egyszer a számlálás megkezdéséhez g. Nyomja meg újra a gombot a számlálás leállításához @

- A fényerő a paradicsomosan csökken. Az időzítő automatikusan elalszik, ha 5 másodpercig nem működik s.d

Forgalmazó

Sunnysoft s.r.o.

Kovanecká 2390/1a

190 00 Prága 9

Cseh Köztársaság

www.sunnysoft.cz

KM5005 / ROTATING ELECTRONIC TIMER



Works with 3 AAA, LR03 batteries, not included.

Insertion and batteries replacement :

Depending of the model, remove cover by using a screwdriver. Put the AAA, LR03 batteries, taking care to match up the polarity indicated. Replace the cover so that it is in the same place.

Magnet in the backside

Warnings :

Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the product before being charged. Different types of batteries or new and used batteries are not to be mixed. Batteries are to be inserted with the correct polarity. Exhausted batteries are to be removed from the product. The supplier terminals are not to be short-circuited. Keep batteries away from children.

LED DISPLAY



UP TO



COUNTDOWN TIMER

- Rotate the button to set the time you want.
- After your countdown time is set, press the button once to start counting ⦿
- When the countdown time counts down to 00 minutes 00 seconds, the digital timer will be buzzing and the screen will blink, the alarm sound will last for 60 seconds.
- Buzzing can be stopped by pressing the button ⦿
- Press the volume button to choose the proper volume.

STOPWATCH

- Press and hold the button for zero clearing ⦿
- When the display shows 00 minutes 00 seconds, press the button once to start counting. Press the button again to stop counting ⦿
- The brightness will be automatically reduced. The timer will auto sleep while it is no operations for 5 seconds.