




Használati utasítás



FA14

Kérjük, használat előtt figyelmesen olvassa el ezeket az utasításokat. Ügyeljen arra, a készüléket szigorúan a kézikönyvben megadott követelményeknek megfelelően használja, és a kézikönyvet a későbbi megfelelően őrizze meg.

A megjelenés



① Levegő kimenet

② Be/sebesség gomb

③ Jelzőfény

④ Légbeömlő C

⑤ típusú bemenet

Használat előtti utasítások

1. A bekapcsolás előtt ellenőrizze a terméket és a tápkábelt, hogy nem sérült-e meg, győződjön meg arról, hogy jó , és szerelje össze őket az utasításoknak megfelelően.

2. A termék töltése előtt ellenőrizze, hogy a használt feszültsége megfelel-e a termék címkéjén szereplő értéknek.

3. Az áramütés és tűzveszély érdekében ne szerelje szét, ne módosítsa és ne javítsa a terméket, és a terméket az eredeti forgalmazó vagy a gyártó által kijelölt szervizközpontban javíttassa.

Használja a címet.

A. Hogyan kell használni

Óvatosan nyújtsa ki a ventilátor lapátjait balra és jobbra úgy, hogy a légkivezető nyílás felfelé mutasson, lógjon a nyaka köré, nyomja meg a bekapcsoló/sebesség gombot, és a ventilátor működésbe lép, hűvös levegőt fújva a feje felé a frissítő élmény érdekében.

B. Táp/sebességkapcsoló

Nyomja meg röviden a bekapcsoló/sebesség gombot az üzemmódba való belépéshez.

első fokozat/második fokozat/harmadik fokozat/negyedik fokozat/ötödik fokozat/kikapcsolás; bármelyik fokozat hosszú megnyomása közvetlenül kikapcsolja a ventilátort.



C. A mutató állapota

Indikátor	A következő jelentése
A fehér fény még mindig ég	Teljesen feltöltött állapot
A fehér fény lassan pislákol	A töltés állapota
A fehér fény egyszer felvillan	Kapcsolási sebességek
A fehér fény még mindig villog	Túl alacsony az akkumulátor töltöttsége
A fehér fény háromszor villan	Az akkumulátor lemerült és nem működik

D. Termék tisztítása

1. A termék tisztítása előtt győződjön meg arról, hogy a tápellátás ki van kapcsolva.
2. Száraz ruhával törölje át a ventilátor testét és a légkivezető nyílást.
3. Soha ne tisztítsa az elektromos alkatrészeket (pl. motor, kapcsoló stb.) vízzel vagy más folyadékkal.
4. Ne érintse meg a tápegységet és az elektromos alkatrészeket nedves kézzel vagy nedves ruhával.
5. Távolítsa el időben a port vagy idegen tárgyakat a nyílásból, hogy megakadályozza a por bejutását a levegő üregébe.

Az akkumulátor eltávolítása

A termék ártalmatlanítása előtt az akkumulátort ki kell venni a termékből. Az akkumulátor eltávolítása előtt a terméket ki kell kapcsolni. Az akkumulátorokat az értékesítési hely előírásainak megfelelően, biztonságosan kell ártalmatlanítani.

1. A számmal távolítsa el a dugót és az alsó csavart, majd nyissa ki a belső fedelet, és távolítsa el az alsó csavart (1. ábra).
2. Használja a számmat a külső fedél felfeszítéséhez (2. ábra).
3. Húzza ki az akkumulátor csatlakozóját, vegye ki az akkumulátort, és a helyi előírásoknak megfelelően ártalmatlanítsa biztonságosan (3. ábra).



1. ábra



2. ábra



3. ábra

Biztonsági figyelmeztetés

A használat biztonságának biztosítása, valamint a sérülések és károk megelőzése érdekében

az Ön és mások tulajdonát, kérjük, tartsa be az alábbi biztonsági óvintézkedéseket. A biztonsági figyelmeztetések figyelmen kívül hagyása esetén a helytelen használat balesethez vezethet.

01. Ez a termék nem gyermekjáték, kérjük, ügyeljen arra, hogy csecsemők és gyermekek ne játszanak ezzel a termékkel játékként. A 14 év alatti gyermekek csak szülői felügyelet mellett használhatják.

02. Ez a termék nem alkalmas olyan felhasználók (beleértve a gyermekeket is) általi használatra, akiknek hiányos a fiziológiája, érzékelése, szellemi képességei, tapasztalattal vagy ismeretekkel, kivéve, ha biztonságosan használják azt a biztonságukért felelős személy felügyelete alatt vagy tudtával.

03. Ne fűjjon közvetlenül az emberi testre hosszabb, különösen és gyermekek esetében, hogy elkerülje a fizikai kellemetlenségeket.

04. Használat közben ne tegyen rá ujjakat, éles tárgyakat, fémtárgyakat stb., amelyek a termék meghibásodását és vagy sérülés veszélyét okozhatják.
05. Az áramütés elkerülése érdekében használat közben kerülje a nedves kezek, nedves törülközők és egyéb dugók használatát.
06. Ez a termék nem vízálló, ne használjon vizet a termék közvetlen öblítésére vagy a fürdőszobában, nagy nedvességben, helyeken. a felhasználásra szánt víz tárolására. Kérjük, időben szárítsa meg a felszíni vizet, mielőtt megpróbálná bekapcsolni a használatot. Ne használja teljesen átázva és vízzel a belsejében.
07. A termék meghibásodásának megelőzése érdekében ne takarja le a kivezető és bemeneti nyílást, például ne akasszon rá ruhákat, törülközőket, ruhákat és egyéb tárgyakat.
08. Tilos a használata és tárolása magas hőmérsékletű (60 °C-nál magasabb) környezetben és zárt helyiségekben, például üvegházakban, építkezéseken, kandallókban, nyitott autótuterekben és más olyan környezetben, ahol a műanyag deformálódása, a széllal együtt lángolás tüzet, az akkumulátor felrobbanását és egyéb meghibásodásokat és baleseteket okozhat.
09. Ne nyomja össze, ne szedje szét és ne szerelje be az akkumulátort hosszabb időre. magas hőmérsékletű (60 °C vagy annál magasabb) környezetben, különben fennáll a folyadékszivárgás vagy robbanás veszélye.
10. Ha a fogyasztók hálózati adaptert használnak a töltéshez, a hálózati adapter bemeneti névleges feszültségének és áramának meg kell felelnie a következőknek
- 5,0 V/2,0 A tartományban, és a használat előtt teljesíteni kell a kötelező nemzeti biztonsági tanúsítványokat.
11. Ez a termék lítium-ion akkumulátort használ, nincs memóriafunkciója, a túltöltés vagy a túlzott kisütés befolyásolja a termék élettartamát, kérjük, időben töltsse fel, és teljesen feltöltve húzza ki a tápegységet. A készülék hosszú ideig tartó töltése után (több mint 3 hónapok) nem használják, kérjük, töltsse fel teljesen.
12. Ha a használat során füst, tűz vagy egyéb meghibásodás lép fel, azonnal kapcsolja ki a készüléket, hogy ne használja tovább, és küldje el a kereskedőnek vagy a gyártónak megoldásért, ne szerelje szét saját maga a veszély elkerülése érdekében.
13. Ne hajlítsa vagy húzza a tápkábelt töltés közben, a rossz érintkezést.

Termék paraméterek

Márka: JisuLife

Modell: FA14

neve: Neck Fan Life3 Watt teljesítmény:

5.0/ 2.0A

Akkumulátor kapacitás: 4000 mAh (14,8Wh/3,7V)

Akkumulátorcella: lítium-ion akkumulátor Töltési

idő: 3,5 - 4,5 óra

Működési idő: 2 - 13,5 óra (a különböző felszereltségtől/használatától függően)

Termék súlya: kb. 270 g

Termékméret: 206× 200× 60 mm

A csomag tartalma

Nyakventilátor Life3 x1 USB-
C tápkábel x1 Kézikönyv x1

A jelen felhasználói kézikönyv tartalma és a termék műszaki specifikációi előzetes értesítés nélkül változhatnak.

Szállító/forgalmazó

Sunnysoft s.r.o.
Kovanecká 2390/1a
190 00 Prague 9
Csehország
www.sunnysoft.cz

Gyártó: Shenzhen Jisu Technology Co., Ltd

Address: 301, Bui ding A, No.8, Changjiangpu 2 Road, He'ao
Community, Yuanshan Street, Longgang District, Shenzhen

URL: www.jisulife.com

Tel: 400-011-8812




User Guide



FA14

Please read this manual carefully before use. Be sure to use it in strict accordance with the requirements of the manual, and keep the manual properly for future use.

Appearance Description



- | | | | |
|----------------------------|---|-----------------------------|---|
| Air Outlet - - - - - | 1 | Air Inlet - - - - - | 4 |
| Switch/Gear Button - - - - | 2 | Type-C Input Port - - - - - | 5 |
| Indicator Light - - - - - | 3 | | |

Precautions Before Use


1. Please check the product and power cord for any damage and make sure they are in good condition and assemble them according to the instructions before powering them on.
2. Before charging the product, please check whether the voltage of the power supply used is consistent with the product label.

3. Please do not disassemble, modify or repair the product to avoid electric shock and fire accidents, and ask the service station designated by the original seller or manufacturer for repair.

How To Use


A. How To Use It

Gently spread the fan blades left and right, with the air outlet facing upwards, hang it around your neck, press the power/speed button, and the fan starts working, blowing cool air towards your head, providing a refreshing experience.



B. Power/Speed Switch

Short press the power/speed button to cycle through the first gear/second gear/third gear/fourth gear/fifth gear/shut-down mode; long press at any gear to shut down directly.



C. Indicator Status Description

Indicator Status	Meaning
White light always on	Fully charged state
White light flashes slowly	State of charge
The white light flashes once	Gears switching
White light keeps flashing	Battery is too low
White light flashes 3 times	Battery low and cannot work


D. Product Cleaning

1. Before cleaning the product, please make sure the power is disconnected.
2. Wipe the fan body and air outlet with a dry cloth.
3. Never clean electrical components (such as the motor, power switch, etc.) with water or other liquids.
4. Do not touch the power supply and electrical parts with wet hands or wet cloth.
5. Please clean up the dust or foreign objects in the air outlet in time to avoid dust falling into the air cavity.


Remove The Battery

The battery must be removed from the product before disposing of the product; The product must be powered off before removing the battery; Batteries should be safely disposed of in accordance with the regulations of the place of sale.

1. Use a tool to remove the screw plug and the lower screw, then pry open the inner casing and remove the lower screw (Figure One).
2. Use a tool to pry open the outer casing (Figure Two).
3. Pull out the battery connector and remove the battery, dispose of it safely in accordance with local regulations (Figure Three).



(Figure One)



(Figure Two)



(Figure Three)

Safety Precautions

To ensure the safety of use and to avoid injury and property damage to you and others, please observe the following safety precautions; Incorrect use without observing the safety warnings may lead to accidents.

01. This product is not a child's toy, please ensure that infants and children do not play with this product as a toy; Children under 14 years of age, please use it under the supervision of a guardian.
02. This product is not intended for use by users (including children) with inadequate physiology, perception, mental

ability, experience ,or knowledge, unless used safely under the supervision or knowledge of a person responsible for their safety.

03. Please do not blow directly on the human body for a long time, especially the elderly and children, to avoid physical discomfort.
04. When using, please do not put fingers, sharp objects and metal objects, etc., which will cause product failure and the risk of electric shock, or injury.
05. When using, prohibit the use of wet hands, wet towels and other plugging power to avoid electric shock.
06. This product is not waterproof, please do not use water to directly rinse the product or in the bathroom, heavy moisture, water storage places to use; surface water, please dry in time to dry before trying to turn on the use; completely soaked and internal water into the prohibition of re-use.
07. Do not cover the air outlet and air inlet, such as hanging clothes, towels, clothes, and other items, so as not to cause product failure.
08. Prohibit the use and storage in high temperature (higher than 60 °C) environments and confined spaces, such as greenhouses, construction sites, fireplaces, exposed car rooms and other environments, which will cause plastic deformation, flame with the wind to cause fire, battery explosion and other failures and accidents.
09. Do not squeeze, disassemble the battery or place the battery in a high-temperature environment (60°C and above) for a long time, otherwise there may be a risk of liquid leakage or explosion.
10. If consumers use the power adapter to charge, the power adapter input rated voltage and current should be within 5.0V $\pm$ 2.0A, and the national mandatory safety certification

before use.

11. This product uses lithium-ion battery, no memory function, overcharge or overdischarge will affect the service life of the product, please charge in time and disconnect the power after full charge, long time (more than 3 months) do not use please fully charge.
12. If there is smoke, fire and other failures in use, please immediately turn off the power to stop using, and send it to the dealer or manufacturer to deal with, do not disassemble themselves to avoid danger.
13. Do not bend or pull the power cord during charging to avoid poor contact.

Product Parameters

Brand: JisuLife

Product Model: FA14

Product Name: Neck Fan Life3

Input: 5.0V $\overline{=}$ 2.0A

Battery Capacity: 4000mAh(14.8Wh/3.7V)

Battery Cell: Lithium-ion Battery

Charging Time: 3.5-4.5h

Operating Time: 2-13.5h(depending on different gears/use scenarios)

Product Weight: about 270g

Product Size: 206×200×60mm

Packing Accessories

Neck Fan Life3 * 1

USB-C Charging Cable * 1

Manual * 1

The contents in this user manual and the technical specification of the product will be changed without prior notice.

www.sunnysoft.cz

Manufacturer: Shenzhen Jisu Technology Co., Ltd

Address: 301, Building A, No.8, Changjiangpu 2 Road, He'ao Community, Yuanshan Street, Longgang District, Shenzhen

URL: www.jisulife.com

Tel: 400-011-8812



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

"NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."